## **Understanding Your NorthWestern Electric Meter**

## **Net Metering Customers**



**Segment Test** Tests the LCDs to visually ensure the display will be correct.



**Network Link Status** Network Link Status – Informs Northwestern Energy how well the meter is communicating.



**Sync Network Status** SYCNET- Meter is sync'd to the NorthWestern network.



**Disconnect Status** Internal disconnect status screen -Only appears when the meter is in a disconnected state.



2000141408

**Registration Status** Reg - Meter is registered to the network.



## **Net Kilowatt Hours Delivered**

01 = Net Kilowatt Hours Register The net value between the kilowatt hours delivered (register 02) and kilowatt hours received (register 03). This is the billing register for net metering customers.



**Kilowatt Hours Delivered** 02 = Kilowatt Hours Delivered Register The kilowatt hours delivered to the customer from NorthWestern Energy.



**Kilowatt Hours Received** 03 = Kilowatt Hours Received Register The kilowatt hours NorthWestern has received from a net metering customer.



**Max Kilowatts Delivered** 

04 = Max Kilowatts Delivered The current max demand is displayed in kilowatts. Demand charges are for customers with a demand rate type. This screen is displayed whether they are a demand customer or not.

## How to tell if you are producing or receiving?



Arrow pointing right, customer is receiving from NorthWestern



Arrow pointing left, NWE is receiving from the customer.

